

Plastic Wheel Spacer



Plastic Spacer is easily positioned on reinforcement steel and has a special locking arrangement to minimize the risk of the spacer becoming dislodged when in position. Its rigidity is strong enough to withstand the normal working pressure exerted on it whilst the formwork is being placed, but it is sufficiently flexible to be readily fixed on reinforcing steel of different bar sizes.

- Plastic wheel spacers are used to ensure that correct cover is maintained throughout the structure.
- Cover from : min. 20mm – max. 75mm
- Bar size from : min. 06mm – max. 25mm